



Industrial LoRaWAN[®] Gateway

UG56

Quick Guide



Safety Precautions

Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.

- The device must not be modeled in any way.
- Do not place the device close to objects with naked flames.
- Do not place the device where the temperature is below/above the operating range.
- Do not power on the device or connect it to another electrical device when installing.
- Check lightning and water protection when used outdoors.
- Do not connect or power the equipment using cables that have been damaged.

Related Documents


This Quick Start Guide only explains the installation of Milesight UG56 LoRaWAN® Gateway. For more functionality and advanced settings, please refer to the relevant documents as below.

Document	Description
UG56 Datasheet	Datasheet for UG56 LoRaWAN® Gateway.
UG56 User Guide	Users can refer to the guide for instruction on how to log in the web GUI, and how to configure all the settings.

The related documents are available on Milesight website: <https://www.milesight-iot.com>

Declaration of Conformity

UG56 is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



For assistance, please contact
Milesight technical support:
Email: iot.support@milesight.com
Support Portal: support.milesight-iot.com
Tel: 86-592-5085280
Fax: 86-592-5023065

Revision History

Date	Doc Version	Description
Aug.8, 2022	V1.0	Initial version
Apr. 3, 2023	V1.1	Add external cellular antenna option and installation
Aug. 2, 2024	V1.2	Add default WLAN connection password
Jan. 20, 2025	V1.3	<ol style="list-style-type: none">1. Add optional accessories: DIN rail clip and adapter2. Add DIN Rail Mounting steps
April 11, 2025	V 1.4	<ol style="list-style-type: none">1. Remove wired access method2. Update Wi-Fi connection and network server steps

Contents

1. Packing List	5
2. Hardware Introduction	5
2.1 Overview	5
2.2 Dimensions (mm)	6
2.3 LED Indicators	6
2.4 Reset Button	7
3. Hardware Installation	8
3.1 SIM & Micro SD Installation	8
3.2 Antenna Installation	8
3.3 Power Supply	9
3.4 Gateway Installation	10
4. Web GUI Access	11
5. Network Connection	13
5.1 Configure the Ethernet Connection	13
5.2 Configure the Cellular Connection (Cellular Version Only)	14
5.3 Configure the Wi-Fi Connection	15
6. Packet Forwarder Configuration	17
7. Network Server Configuration	19
7.1 Connect to Milesight IoT Cloud	19
7.2 Add End Devices	20
7.3 Connect to MQTT/HTTP Server	24

1. Packing List


Before you begin to install the UG56 LoRaWAN® Gateway, please check the package contents to verify that you have received the items below.



1 × UG56 Device



1 × LoRaWAN® Magnetic Antenna



1 × Wall Mounting Bracket



2 × Bracket Fixing Screws (M3)



4 × Wall Mounting Kits



1 × Quick Start Guide




1 × Warranty Card




1 × Cellular Magnetic Antenna (Cellular Version Only)



1 × Type-C Cable (1m) & Power Adapter (Optional)



1 × AC/DC-DC Power Converter Kit (Optional)




1 × DIN Rail Clip Kit (Optional)

! If any of the above items is missing or damaged, please contact your sales representative.


2. Hardware Introduction

2.1 Overview




- ① LoRaWAN® Antenna Connector
- ② SIM Slot
- ③ Micro SD Slot
- ④ Reset Button
- ⑤ Cellular Antenna Connector (Cellular Version Only)

Note: It is necessary to open the front cover to see the slots and reset button.



- ⑥ LED Indicators
- ⑦ Type-C Power & Console Port
- ⑧ Ethernet Port (PoE)

2.2 Dimensions (mm)



2.3 LED Indicators

LED	Indication	Status	Description
SYS	System Status	Off	The system is starting up
		Red Light	The system goes wrong
		Green Light	The system is running properly
LoRa	LoRa Status	Off	Packet Forwarder mode is running off
		On	Packet Forwarder mode is running well
Ethernet Port	Link Indicator (Yellow)	Off	Disconnected or connect failure
		On	Connected
		Blinking	Transmitting data

	Rate Indicator (Green)	Off	Other modes
		On	100 Mbps mode

2.4 Reset Button

Function	Description	
	SYS LED	Action
Reset	Static Green	Press and hold the reset button for more than 5 seconds.
	Static Green → Rapidly Blinking	Release the button and wait.
	Off → Static Green	The gateway resets to factory default.


3. Hardware Installation

3.1 SIM & Micro SD Installation

Remove the front panel of the device, insert the SIM card or micro SD card into the corresponding slot.

Note:

- Before inserting, ensure this gateway supports cellular feature which the PN includes “-Lxxxx” on the label.
- UG56 does not support hot plugging (also called hot swapping). please turn off the power before you insert or take off cards.




3.2 Antenna Installation


Rotate antennas into the antenna connectors.

Note:

- The antenna should be installed vertically, with the magnetic base attached to a metal surface.
- Keep the antenna away from walls and ensure there are no obstacles around it.
- For better coverage, it is recommended to position the antenna at a higher location.
- Place the antenna near windows when used indoors.
- Keep a distance of at least 50 cm between antennas.




If you need to fix the LoRaWAN® fiber-glass antenna to a pole, please pass the LoRaWAN® antenna through the antenna clamp and fix it with 4 screws, then wrap the U-bolt around a pole and fix the clamp with nuts and other accessories.




3.3 Power Supply

UG56 can be powered by 802.3af standard PoE or Type-C port (5 VDC). If both are connected, the device will be powered by the former method (PoE).


- **Power by a PoE Switch**



- **Power by a PoE injector**



- **Power by a Type-C Port**




Note: When connecting, Ethernet cable of UG56 device side should be installed first, otherwise, PoE devices or gateway may be damaged.

3.4 Gateway Installation


Before you get started, make sure all fittings are installed and the power supply is disconnected.

Wall Mounting

1. Fix the wall mounting bracket to the device with 2 x M3 bracket fixing screws.




2. Drill 4 holes on the wall according to the wall mounting bracket, then fix the wall plugs into the wall.
3. Fix the device to the wall plugs with M3 wall mounting screws. When installation, it's suggested to fix the upper two screws first.




DIN Rail Mounting

Note: only new hardware devices support DIN rail mounting.

1. Fix the mounting clip to the device with 3 fixing screws.



2. Hang the device to the DIN rail. The width of DIN rail is 3.5cm.



4. Web GUI Access


UG56 provides a web-based configuration interface for management. If this is the first time you configure the gateway, please use the default settings below:

Username: **admin**

Password: **password**

Browser: **Chrome(recommended)**

1. Enable wireless network connection on your computer and search for access point "**Gateway_*******" to connect it, the default Wi-Fi password is **iotpassword**.
2. Open a web browser on your PC (Chrome is recommended) and type in the IP address **192.168.1.1** to access the web GUI, enter the username and password, click "Login".



If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

3. After logging the web GUI, follow the guide to complete the basic configurations. It's suggested that you change the password for the sake of security.

Change Your Default Password

For your device security, please change the default password in time.

Old Password

New Password

Confirm New Password

4. You can view system information and perform configuration of the gateway.

The screenshot displays the Milesight gateway management web interface. At the top left is the Milesight logo. In the top right corner, there is a user profile for 'admin' and a refresh icon. A prominent orange banner across the top of the main content area reads: "For your device security, please change the default password".

The interface is divided into several sections:

- Left Sidebar:** A vertical navigation menu with items: Status, Packet Forwarder, Network Server, Network (with a right-pointing arrow), System (with a right-pointing arrow), Maintenance (with a right-pointing arrow), and APP (with a right-pointing arrow).
- Top Navigation:** A horizontal menu with tabs: Overview (selected), Cellular, Network, WLAN, VPN, Routing, and Host List.
- Main Content Area:** Titled "System Information", it displays a table of gateway details:

Model	UG56-L00E-915M
Region	US915
Serial Number	6041C2232749
Firmware Version	56.0.0.1-a2
Hardware Version	V1.0
Local Time	2022-08-10 16:31:28 Wednesday
Uptime	03:10:23
CPU Load	6%
RAM (Available/Capacity)	194MB/512MB (37.89%)
eMMC (Available/Capacity)	6.2GB/7.0GB (88.46%)
- Right Sidebar (Help):** A vertical list of help topics with expandable descriptions:
 - Model:** Show the model name of gateway.
 - Region:** Show the Region of gateway.
 - Serial Number:** Show the serial number of gateway.
 - Firmware Version:** Show the current firmware version of gateway.
 - Hardware Version:** Show the current hardware version of gateway.
 - Local Time:** Show the current local time of system.
 - Uptime:** Show the information on how long the gateway has been running.

At the bottom right of the main content area, there is a "Manual Refresh" dropdown menu and a blue "Refresh" button.

5. Network Connection

This section explains how to connect the gateway to network via WAN connection, Wi-Fi or cellular.

5.1 Configure the Ethernet Connection

1. Go to **Network > Interface > Port** page to select the connection type and configure Ethernet port information, click "Save & Apply" for changes to take effect.

The screenshot shows the 'Port' configuration page in the Milesight gateway interface. The page has tabs for 'Port', 'WLAN', 'Cellular', 'Loopback', and 'VLAN Trunk', with 'Port' selected. Below the tabs, there is a section for 'Port_1' configuration. The fields are as follows:

Port	eth 0
Connection Type	Static IP
IP Address	192.168.45.190
Netmask	255.255.255.0
Gateway	192.168.45.1
MTU	1500
Primary DNS Server	8.8.8.8
Secondary DNS Server	
Enable NAT	<input checked="" type="checkbox"/>

Note: If there is IP conflict when changing the IP address of Ethernet port, please change the subnet of WLAN first.


The screenshot shows the 'WLAN' configuration page in the Milesight gateway interface. The page has tabs for 'Port', 'WLAN', 'Loopback', and 'VLAN Trunk', with 'WLAN' selected. The 'WLAN' section is expanded, showing the following settings:

Enable	<input checked="" type="checkbox"/>
Work Mode	AP
[Blurred configuration options]	
IP Setting	
Protocol	Static IP
IP Address	192.168.10.1
Netmask	255.255.255.0

The IP Address and Netmask fields are highlighted with a red box.

2. Connect Ethernet port of gateway to devices like router or modem.

3. Go to **Maintenance > Tools > Ping** to check network connectivity.



5.2 Configure the Cellular Connection (Cellular Version Only)

1. Go to **Network > Interface > Cellular > Cellular Setting** page to enable cellular settings and configure the necessary cellular info of the SIM card, then click "Save" and "Apply" for changes to take effect.

The screenshot shows the 'Cellular Setting' configuration page with the following settings:

- Enable:
- Network Type: Auto (dropdown)
- APN: (empty text field)
- Username: (empty text field)
- Password: (empty text field)
- Access Number: (empty text field)
- PIN Code: (empty text field)
- Authentication Type: None (dropdown)
- Roaming:
- Customize MTU:
- MTU: 1500 (text field)
- Enable IMS:
- SMS Center: (empty text field)

2. Go to **Status > Cellular** page to view the status of the cellular connection. If it shows "Connected", it means the SIM has dialed up successfully.


Overview	Packet Forward	Cellular	Network	WLAN
Modem				
Status	Ready			
Model	EC25			
Version	EC25ECGAR06A07M1G			
Signal Level	23asu (-67dBm)			
Register Status	Registered (Home network)			
IMEI	860425047368939			
IMSI	460019425301842			
ICCID	89860117838009934120			
ISP	CHN-UNICOM			
Network Type	LTE			
PLMN ID				
LAC	5922			
Cell ID	340db83			
Network				
Status	Connected			
IP Address	10.132.132.59			
Netmask	255.255.255.240			
Gateway	10.132.132.60			

5.3 Configure the Wi-Fi Connection

1. Go to **Network > Interface > Port** page to select connection type as **Static IP** and configure an IP address for the Ethernet WAN port.

Status	Port	WLAN	Cellular	Loopback	VLAN Trunk
Packet Forwarder	Port_1				
Network Server	Port	eth 0			
Protocol Integration	Connection Type	Static IP			
Network	IP Address	192.168.23.150			
Interface	Netmask	255.255.255.0			
Firewall	Gateway	192.168.23.1			
DHCP	MTU	1500			
DDNS	Primary DNS Server	8.8.8.8			
	Secondary DNS Server	223.5.5.5			
	Enable NAT	<input checked="" type="checkbox"/>			

2. Connect PC to UG56 ETH port directly or through PoE injector.
3. Assign the IP address to computer manually. Take Windows 10 system as an example:



- Open a Web browser and type in the IP address of the Ethernet port to access the web GUI.
- Go to **Network > Interface > WLAN** and click **Scan** to search for WiFi access point.

Port	WLAN	Cellular	Loopback				
< GoBack							
SSID	Channel	Signal	Cipher	BSSID	Security	Frequency	
AAA	Auto	-61dBm	AES	24:e1:24:f0:c4:13	WPA-PSK/WPA2-PSK	2412MHz	Join Network

- Select one access point and click **Join Network**, then type the password of the access point.

Port	WLAN	Cellular	Loopback
WLAN			
Enable	<input checked="" type="checkbox"/>		
Work Mode	Client		Scan
SSID	AAA		
BSSID	24:e1:24:f0:c4:13		
Encryption Mode	WPA-PSK/WPA2-PSK		
Cipher	AES		
Key	*****		
IP Setting			
Protocol	DHCP Client		

Click **Save** and **Apply** buttons after all configurations are done.

- Go to **Status > WLAN** to check the connection status of the client. If it shows "Connected", it means gateway connects to Wi-Fi successfully.

WLAN Status	
Wireless Status	Enabled
MAC Address	24:e1:24:f0:de:14
Interface Type	Client
SSID	AAA
Channel	Auto
Encryption Type	WPA-PSK/WPA2-PSK
Cipher	AES
Status	Connected
IP Address	192.168.1.145
Netmask	255.255.255.0
Connection Duration	0 days, 02:44:45

8. Go to **Network > Failover > WAN Failover** to switch the wlan0 as main interface, then gateway can use the Wi-Fi to access the network.

Main Interface	Backup Interface	Startup Delay(s)	Up Delay(s)	Down Delay(s)	Track ID	Operation
wlan0	eth 0	30	0	0	1	[X] [+]

Save

6. Packet Forwarder Configuration

UG56 has installed multiple packet forwarders including Semtech, Chirpstack, etc. This section explains how to connect the gateway to network servers.

⚠ Make sure the gateway connects to the network as shown in [Section 5](#).

1. Go to **Packet Forwarder > General** page and click **+** to add a network server.

The screenshot shows the 'General Setting' page for a Packet Forwarder. The left sidebar contains navigation options: Status, Packet Forwarder, Network Server, Network, System, Maintenance, and APP. The main content area has tabs for General, Radios, Advanced, Custom, and Traffic. Under 'General Setting', the following fields are visible:

- Gateway EUI: 24E124FFFEF
- Gateway ID: 24E124FFFEF
- Frequency-Sync: Disabled

Below these is the 'Multi-Destination' section, which contains a table:

ID	Enable	Type	Server Address	Connect Status	Operation
0	Enabled	Embedded NS	localhost	Connected	[Edit] [Close]
+					

A 'Save & Apply' button is located at the bottom left of the configuration area.

2. Fill in the server information and enable this server.

The screenshot shows a configuration form for a server. The 'Enable' checkbox is checked. The 'Type' dropdown menu is set to 'Semtech'. The 'Server Address' dropdown menu is set to 'eu1.cloud.thethings.network'. The 'Port Up' and 'Port Down' input fields both contain the value '1700'. A blue 'Save' button is positioned at the bottom center of the form.

3. Go to **Packet Forwarder > Radio** page to configure the center frequency and channels. The channels of the gateway and network server need to be the same.

The screenshot shows the 'Radio' configuration page. At the top, the 'Region' dropdown is set to 'US915'. Below this is a table with two rows:

Name	Center Frequency/MHz
Radio 0	904.3
Radio 1	905.0

Below this table is the 'Multi Channels Setting' section, which contains a table with 8 rows:

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	903.9
<input checked="" type="checkbox"/>	1	Radio 0	904.1
<input checked="" type="checkbox"/>	2	Radio 0	904.3
<input checked="" type="checkbox"/>	3	Radio 0	904.5
<input checked="" type="checkbox"/>	4	Radio 1	904.7
<input checked="" type="checkbox"/>	5	Radio 1	904.9
<input checked="" type="checkbox"/>	6	Radio 1	905.1
<input checked="" type="checkbox"/>	7	Radio 1	905.3

4. Add the gateway on network server page. For more details about the network server connection please refer to [Milesight IoT Support portal](#).

7. Network Server Configuration

The gateway can work as a LoRaWAN® network server to receive and analyze the data of LoRaWAN® end devices, and then achieve the flexible integration with different systems.



Make sure the gateway connects to the network as shown in [Section 5](#).

7.1 Connect to Milesight IoT Cloud

1. Go to **Packet Forwarder > General** page to enable the embedded network server.


ID	Enable	Type	Server Address	Connect Status	Operation
0	Enabled	Embedded NS	localhost	Connected	

2. Go to **Packet Forwarder > Radio** page to select center frequency and channels. The channels of the gateway and the end devices need to be the same.


Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	903.9
<input checked="" type="checkbox"/>	1	Radio 0	904.1
<input checked="" type="checkbox"/>	2	Radio 0	904.3
<input checked="" type="checkbox"/>	3	Radio 0	904.5
<input checked="" type="checkbox"/>	4	Radio 1	904.7
<input checked="" type="checkbox"/>	5	Radio 1	904.9
<input checked="" type="checkbox"/>	6	Radio 1	905.1
<input checked="" type="checkbox"/>	7	Radio 1	905.3

3. Go to **Network Server > General** page to enable the network server and “Milesight IoT Cloud” mode.


Note: after this mode is enabled, the other settings of network server will be not allowed to edit.



4. Log in the Milesight IoT Cloud. Then go to **My Devices** page and click “+New Devices” to add gateway to Milesight IoT Cloud via SN. Gateway will be added under “Gateways” menu.



5. The gateway is online on Milesight IoT Cloud.



7.2 Add End Devices

1. Go to **Packet Forwarder > General** page to enable the embedded network server.

The screenshot shows the 'Packet Forwarder' configuration page. The 'General Setting' section includes:

- Gateway EUI: 24E124FFFEF
- Gateway ID: 24E124FFFEF
- Frequency-Sync: Disabled

The 'Multi-Destination' section contains a table with the following data:

ID	Enable	Type	Server Address	Connect Status	Operation
0	Enabled	Embedded NS	localhost	Connected	[Edit] [Delete] [Add]

2. Go to **Packet Forwarder > Radio** page to select the center frequency and channels. The channels of the gateway and the end devices need to be the same.

The screenshot shows the 'Radio' configuration page. The 'Region' is set to US915. The main table shows the following radio configurations:

Name	Center Frequency/MHz
Radio 0	904.3
Radio 1	905.0

The 'Multi Channels Setting' section includes a table with the following data:

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	903.9
<input checked="" type="checkbox"/>	1	Radio 0	904.1
<input checked="" type="checkbox"/>	2	Radio 0	904.3
<input checked="" type="checkbox"/>	3	Radio 0	904.5
<input checked="" type="checkbox"/>	4	Radio 1	904.7
<input checked="" type="checkbox"/>	5	Radio 1	904.9
<input checked="" type="checkbox"/>	6	Radio 1	905.1
<input checked="" type="checkbox"/>	7	Radio 1	905.3

3. Go to **Network Server > General** page to enable the network server mode.

The screenshot shows the 'Network Server' configuration page. The 'General Setting' section includes:

- Enable:
- Milesight IoT Cloud:
- NetID: 010203
- Join Delay: 5 sec
- RX1 Delay: 1 sec
- Lease Time: 876000-0-0 hh-mm-ss
- Log Level: info

4. Go to **Network Server > Application** to add a new application.

Applications

ID	Name	Description	Operation
1	Test	Test	 
			

Applications

Name

Description

Metadata

Data Transmission

Type	Operation
	

5. Go to **Network Server > Device** page and click **Add** to add a LoRaWAN® end device. You can also click **Bulk Import** to use template to add bulk devices at once.

Device



Device Name	Device EUI	Device-Profile	Application	Last Seen	Activated	Operation
No matching records found						

6. Fill in the information of the end device and click **Save&Apply**. The information can be found on the end device's configuration page or from manufacturer's manuals. Here are the default settings of Milesight end devices:

- Device EUI: this can be found on the device.
- Device-Profile: OTAA type files
- Payload Codec: select the model
- fPort: 85
- Application Key: select Default Value. If you use random keys, please select Custom Value.

Device Name	<input type="text" value="lora-sensor"/>
Description	<input type="text" value="a short description of your node"/>
Device EUI	<input type="text" value="0000000000000000"/>
Device-Profile	<input type="text" value="ClassA-OTAA"/>
Application	<input type="text" value="cloud"/>
Payload Codec	<input type="text"/>
fPort	<input type="text" value="1"/>
Frame-counter Validation	<input type="checkbox"/>
Application Key	<input checked="" type="radio"/> Default Value <input type="radio"/> Custom Value
Device Address	<input type="text"/>
Network Session Key	<input type="text"/>
Application Session Key	<input type="text"/>
Uplink Frame-counter	<input type="text" value="0"/>
Downlink Frame-counter	<input type="text" value="0"/>

7. Go to **Network Server > Packets** page to check the packets from LoRaWAN® end devices. The type starts from “Up” means uplinks and “Dn” means downlinks.

Device EUI/Group	Gateway ID	Frequency	Datarate	RSSI/SNR	Size	Fcnt	Type	Time	Details
24E12	24E124	868300000	SF7BW125	-44/14.5	23	678	UpUnc	2025-04-03 10:09:25+08:00	!
24E12	24E124	868500000	SF7BW125	-44/10.2	23	677	UpUnc	2025-04-03 10:08:25+08:00	!
24E12	24E124	868100000	SF7BW125	-53/14.0	10	289	UpUnc	2025-04-03 10:07:46+08:00	!
24E12	24E124	868100000	SF7BW125	-39/14.2	23	676	UpUnc	2025-04-03 10:07:25+08:00	!
24E12	24E124	868100000	SF7BW125	-40/13.8	23	675	UpUnc	2025-04-03 10:06:25+08:00	!
24E12	24E124	868100000	SF7BW125	-40/14.0	23	674	UpUnc	2025-04-03 10:05:25+08:00	!
24E12	24E124	868500000	SF7BW125	-40/11.5	23	673	UpUnc	2025-04-03 10:04:25+08:00	!
24E12	24E124	868300000	SF7BW125	-49/13.8	18	0	JnReq	2025-04-03 10:04:16+08:00	!

Click **Details** to check the properties and payload contents of packets.

Packet Details	
Bandwidth	120
SpreadFactor	7
Bitrate	0
CodeRate	4/5
SNR	13.5
RSSI	-54
Power	-
Payload(b64)	AXVjA2fqAARoPA==
Payload(hex)	0175630367ea0004683c
JSON	{ "battery": 99, "humidity": 30, "temperature": 23.4 }
MIC	7f3664cd

7.3 Connect to MQTT/HTTP Server

The gateway supports choosing the data transport protocol to send the data of device within this application to third-party servers. One application supports to add a MQTT transmission or a HTTP (HTTPS) transmission at most.

1. Go to **Network Server > Application** to select the application to edit.
2. Click  to add a data transmission type.

HTTP or HTTPS:

Step 1: select HTTP or HTTPS as transmission protocol.

Type	HTTP
------	------

Step 2: Enter the destination URL. Different types of data can be sent to different URLs.

URL	
Data Type	URL
Uplink data	<input type="text"/>
Join notification	<input type="text"/>
ACK notification	<input type="text"/>
Error notification	<input type="text"/>

Enter the header name and header value if there is user credentials when accessing the HTTP(s) server.

| HTTP Header

Header Name	Header Value	Operation
<input type="text"/>	<input type="text"/>	<input type="button" value="X"/>
		<input type="button" value="+"/>

MQTT:

Step 1: select the transmission protocol as MQTT.

Step 2: Fill in MQTT broker general settings.

Type

Status -

| General

Broker Address

Broker Port

Client ID

Connection Timeout/s

Keep Alive Interval/s

Data Retransmission

Step 3: Select the authentication method required by the server.

If you select user credentials for authentication, you need to enter the username and password for authentication.

| User Credentials

Enable

Username

Password

If certificate is necessary for verification, please select mode and import CA certificate, client certificate and client key file for authentication.

| TLS

Enable

Mode

CA File

Client Certificate File

Client Key File

Step 4: Enter the topics to receive data or send downlinks, and choose the QoS.

| Topic

Data Type	topic	Retain	
Uplink data	<input type="text"/>	<input type="checkbox"/>	<input type="text" value="QoS 0"/> ▾
Downlink data	<input type="text"/>	<input type="checkbox"/>	<input type="text" value="QoS 0"/> ▾
Multicast downlink data	<input type="text"/>	<input type="checkbox"/>	<input type="text" value="QoS 0"/> ▾
Join notification	<input type="text"/>	<input type="checkbox"/>	<input type="text" value="QoS 0"/> ▾
ACK notification	<input type="text"/>	<input type="checkbox"/>	<input type="text" value="QoS 0"/> ▾
Error notification	<input type="text"/>	<input type="checkbox"/>	<input type="text" value="QoS 0"/> ▾
Request data	<input type="text"/>	<input type="checkbox"/>	<input type="text" value="QoS 0"/> ▾
Response data	<input type="text"/>	<input type="checkbox"/>	<input type="text" value="QoS 0"/> ▾

[END]