



How to mount the adapter for M28 x 1.5 valves and fit it to the Vicki Smart Radiator Thermostat?

If your radiator features an M28 x 1.5 threaded valve, this adapter ensures a secure and stable fit.




The adapter comes with several pin extenders and to determine the correct ones for your radiator, you need to measure the distance from the tip of the pin to the start of the valve thread.




SAM Slovan

H ca. 1,0 - 3,0 mm



TA Comap Markaryds

ca. 6,5 - 8,5 mm





Herz MMA Remag

ca. 8,5 - 10 mm



Other

ca. 10 - 12 mm



After choosing the appropriate pin extender you need to insert it into the adapter, ensuring that the extender's head aligns with the valve pin. Then, securely mount the assembled adapter, making sure it fully covers the valve thread.